

# Matrixcote<sup>®</sup> Prime Concentrate

## Formulations

If you currently have a primary slurry formulation, use the same percentages and loadings of your current refractories. The following formulations are for casters just starting out.

Intended Slurry Use	Target Slurry Density (g/ml)	Target Viscosity (sec/#5 Zahn)	Formula for 10 Gallons (lbs)				
			Matrixsol <sup>®</sup> 30 colloidal silica	MATRIXCOTE Prime concentrate	DI Water	Ranco-Sil <sup>™</sup> 4 fused silica	Zircon (-200 mesh)
Ferrous	2.99-3.03	17-19	37.4	4.4	2.2	—	206.7
Non-Ferrous	1.69-1.73	22-27	39.0	4.7	2.4	95.4	—
			Formula for 10 Liters (kgs)				
Ferrous	2.99-3.03	17-19	4.49	0.53	0.27	—	14.58
Non-Ferrous	1.69-1.73	22-27	4.81	0.57	0.29	11.47	—

## Application Recommendations

1. Remix the MATRIXCOTE Prime concentrate prior to use to ensure a homogeneous blend of material.
2. For best results, weigh all ingredients when making up a new slurry or making additions to an existing slurry.
3. When building the slurry, add the refractory last. If more than one refractory is used, add the lowest density refractory first: fused silicas (2.2 g/cc), alumino silicates (2.7 g/cc), zircon (4.5 g/cc). Add refractory slowly for best results.
4. New and makeup slurries must be prepared with a propeller mixer, not in a rotating tank. This ensures proper dispersion of the refractory particles. The propeller mixer must be of adequate HP and RPM. Excessive mixing action can introduce air into the slurry and cause erratic viscosity and/or bubbles in the slurry coat.
5. As with any slurry, the viscosity of the slurry must be stable before use. A stable viscosity is one that does not change by more than 1 second when checked at 1 hour intervals. Viscosity can be increased by adding more refractory and decreased by adding more binder.
6. It is required to replace water lost to evaporation. When water is needed (based on test results for viscosity and/or binder solids), use distilled or deionized water as opposed to tap water, which can contain contaminants that can negatively affect slurry life.
7. Antifoam, wetting and bactericide agents are already formulated into MATRIXCOTE Prime concentrate and other additions may not be compatible. Contact R&R's technical team before making these additions to the slurry.
8. Patterns must be clean and free from silicones or other contaminants before dipping.
9. It is not usually necessary to use a prewet before applying the first primary coat to the wax pattern. If a prewet is needed, use MATRIXSOL 30 colloidal silica only.
10. If a prewet is needed between coats, the MATRIXSOL 30 colloidal silica should be diluted to 27% binder solids (binder to water ratio of 5.8:1 by volume, 6.9:1 by weight). Drain the prewet well so that no pockets of liquid are left on the pattern.

### RANSOM & RANDOLPH

Maumee, OH 43537 USA

Toll Free: 800.800.7496

Phone: 419.865.9497

Fax: 419.865.9997

www.ransom-randolph.com

Issue Date: 021617 / Replaces: 081116



# Matrixcote<sup>®</sup> Prime Concentrate

## Slurry Control Procedures

Slurry Control Worksheets are available for download at [www.ransom-randolph.com](http://www.ransom-randolph.com) under resources. Slurry Control Worksheets allow you to input data directly and help you calculate values.

## Slurry Testing Frequency

R&R recommends running the following tests accordingly.

Slurry Test	Recommended Testing Frequency
Slurry Viscosity	Two Times Per Shift
Binder Solids	Two Times Per Week
Binder pH	Weekly

## Target Binder Solids Range

The target binder solids range for MATRIXCOTE Prime concentrate is 28.8%-30.8% by weight.

Specific Gravity	Binder Solids	Specific Gravity	Binder Solids	Specific Gravity	Binder Solids
1.160	26.8	1.173	28.8	1.186	30.9
1.161	27.0	1.174	29.0	1.187	31.0
1.162	27.1	1.175	29.1	1.188	31.2
1.163	27.3	1.176	29.3	1.189	31.3
1.164	27.4	1.177	29.5	1.190	31.5
1.165	27.6	1.178	29.6	1.191	31.6
1.166	27.7	1.179	29.8	1.192	31.8
1.167	27.9	1.180	29.9	1.193	31.9
1.168	28.1	1.181	30.1	1.194	32.1
1.169	28.2	1.182	30.2	1.195	32.3
1.170	28.4	1.183	30.4	1.196	32.4
1.171	28.5	1.184	30.6	1.197	32.6
1.172	28.7	1.185	30.7	1.198	32.7



### RANSOM & RANDOLPH

Maumee, OH 43537 USA  
 Toll Free: 800.800.7496  
 Phone: 419.865.9497  
 Fax: 419.865.9997  
[www.ransom-randolph.com](http://www.ransom-randolph.com)

Issue Date: 021617 / Replaces: 081116

*Investing with Innovation<sup>™</sup>*

# Matrixcote<sup>®</sup> Prime Concentrate

## Safety

OSHA-approved respiratory protection should always be worn to avoid inhalation of respirable silica dust, which can result in an irreversible lung disease, silicosis. Such exposure includes slurry makeup, casting, knockout and cleanup. Refer to SDS for specific details.

## Storage & Handling

Keep from freezing. MATRIXCOTE Prime concentrate must be maintained above 35 °F (2 °C) to prevent the material from precipitating irreversibly and making the product unsuitable for use. Binder stored in transparent or translucent containers should be sheltered from direct sunlight. Shelf life is 1 year from date (MMDDYY) in batch lot number on label. Rotate stock to maximize shelf life.

## Technical Tips

For additional information and recommendations, refer to the Shell Building, Slurry Control, Autoclaving and FlashFire Dewax Method Technical Tips available for download at [www.ransom-randolph.com](http://www.ransom-randolph.com) under resources.

*As the conditions or methods of use are beyond our control, we do not assume any responsibility and expressly disclaim any liability for any use of this product. Information contained herein is believed to be true and accurate but all statements or suggestions are made without warranty, expressed or implied, regarding accuracy of the information, the hazards connected with the use of the material or the results to be obtained from the use thereof. Compliance with all applicable federal, state, and local regulations remains the responsibility of the user. All potential liability related to the sale and use of this product is limited to the cost of the particular goods sold in their respective transactions.*



### RANSOM & RANDOLPH

Maumee, OH 43537 USA

Toll Free: 800.800.7496

Phone: 419.865.9497

Fax: 419.865.9997

[www.ransom-randolph.com](http://www.ransom-randolph.com)

Issue Date: 021617 / Replaces: 081116

*Investing with Innovation<sup>™</sup>*