

# RTV2 SILICONE RUBBER



R&R offers a full range of silicone rubber, room temperature vulcanized (RTV2) materials, for model and mold making. RTV2 silicone rubber is ideal for use in mold making applications including: rapid prototyping, jewelry, glass art, art sculpture, and concrete molding.

RTV2 silicone rubber is platinum-curing and composed of two components, base and catalyst, that mix together and vulcanize at room temperature.

## Why use RTV2 Silicone Rubber?

- High dimensional stability over time
- Easy to use
- Most stable polymers available, offering superior reliability
- Vulcanization time can be adjusted, allowing flexible application
- Suited to polyurethane casting materials
- Products are non-toxic
- 1:1 mixing ratio formulas provide easy mixing
- 10:1 mixing ratio formula for transparency

## RTV2 Silicone Rubbers Provide

- Excellent durability over time
- Excellent stability over time
- Zero shrinkage
- Mixing ease
- Increased production speed

## Important Application Tip

Be aware that contact with certain material can inhibit the curing of the RTV2 poly-addition silicone rubber. Common contaminants to be avoided include:

- Natural or synthetic rubber, vulcanized with sulphur derivatives
- Poly-condensation RTV catalyzed with metallic salts
- PVC stabilizing agents
- Amine cured epoxies
- Sulphur, tin and amines derivatives

In case of doubt, carry out a small test by pouring the mixture onto a small area of the object.



## RANSOM & RANDOLPH

3535 Briarfield Boulevard | Maumee, OH 43537 USA  
800.800.7496 | 419.865.9497 | 419.865.9997 (FAX)  
www.ransom-randolph.com



Ransom & Randolph GmbH  
Leipziger Straße 40 | 04571 Rötha Germany  
+49 342 06373999

*Investing with Innovation™*

# RTV2 SILICONE RUBBER

RTV2 silicone rubber	Mixing Ratio	Form	Color	Working Time	Setting Time	Hardness (ShA)
HT33	1:1	Liquid	Red or Translucent	20-22 minutes	3½ hours	33 ± 2
HT 42	1:1	Liquid	Gray	22-26 minutes	2 hours	41
HT 45	1:1	Liquid	Sea Blue or Translucent	10-12 minutes	1-1½ hours	43 ± 3
XTX 45	10:1	Liquid	Translucent	90 minutes	13 hours	41 ± 2
ZA 10 Orange	1:1	Liquid	Orange	15 minutes	2 hours	13
ZA 13 Mold 45	1:1	Liquid	Translucent	40-50 minutes	8 hours	13 ± 2
ZA 22 Mold	1:1	Liquid	Blue	14-17 minutes	1-1½ hours	22 ± 2
ZA 28 Mold	1:1	Liquid	Green	12-15 minutes	1 hour	28 ± 2
ZA 35 Mold	1:1	Liquid	Yellow	12-15 minutes	1 hour	35 ± 2
ZA 35 Mold Fast	1:1	Liquid	Light green	7 minutes	30-40 minutes	35
ZA 50 LT	1:1	Liquid	Blue	15-20 minutes	4 hours	50 ± 3

\*The working time and setting time depends significantly on the temperature and air-humidity. They also vary depending on the size of the cured item.

## Safety

Before handling this material, review the corresponding Safety Data Sheet (SDS).

*As the conditions or methods of use are beyond our control, we do not assume any responsibility and expressly disclaim any liability for any use of this product. Information contained herein is believed to be true and accurate but all statements or suggestions are made without warranty, expressed or implied, regarding accuracy of the information, the hazards connected with the use of the material or the results to be obtained from the use thereof. Compliance with all applicable federal, state, and local regulations remains the responsibility of the user. All potential liability related to the sale and use of this product is limited to the cost of the particular goods sold in their respective transactions.*



## RANSOM & RANDOLPH

3535 Briarfield Boulevard | Maumee, OH 43537 USA  
800.800.7496 | 419.865.9497 | 419.865.9997 (FAX)  
www.ransom-randolph.com



Issue Date: March 25, 2024

Ransom & Randolph GmbH  
Leipziger Straße 40 | 04571 Rötha Germany  
+49 342 06373999

Investing with Innovation™